


MODEST EVE

HOW TO PRINT




To Print:


You can choose to print all the pages of your PDF pattern, or you can preview the file and only print the pattern pieces, and read the instructions from your computer screen.

Very Important:


When you click on File then Print you will get the printer dialogue window. It is very important that you set your Scaling settings to NONE, if you don't the printer will shrink your pattern.





Our patterns are produced with Garment Designer Software from Cochenille Design studio. On the top of every page you will see the title of the pattern in this case “nursingcover”, then a pattern piece title in this case “Shape 1”, then you will see the information you need to put the pattern together in this case “A1” so this is the top of row A the first page. You will also see different placement marks on each corner. There will be corresponding placement marks on the pieces you will need to line up with that corner.



Then at the bottom and sides of the page you will see the placement marks and also the row and number of the page that you will line up with that side.



To put the pattern together place the top of A2 on the bottom of A1 overlapping the placement marks. Tape the corners down. Then place the top of A3 on the bottom of A2, and so forth until you finish Row A.




Then start row B, by placing B1 on the Right side of A1, and continue Row B as you did Row A. Continue this way until you finish all the pages for that pattern piece.

If you have multiple pattern pieces you will come across another A1 - that will be the beginning of the next pattern piece.

Garment Designer

Date: Thursday, October 14, 2010
Size: Standard Misses 10 (Simple Fit)
Part: Shape 1
Length: 6-1/8 in



B1

Garment Designer


Date: Thursday, October 14, 2010


Size: Standard Misses 10 (Simple)

Part: Shape 2

Length: 9-1/8 in

A2





B 2



